





Wall mount Instructions For AC75 Yacht - 42174


What's Included:

- A. 1x Right arm
- B. 1X Left arm
- C. 1x Wall plate
- D. 2x Front stretcher
- E. 2x Wall screw (4.5x50mm)
- F. 2x Wall plug (6x30mm)





Do not over tighten the screws (use a screwdriver not a drill).



Remove the inner fin and store it on the wall mount. Use the spare technic pins to store the part as shown.

