





## Wall Mount Instructions Ghost & Phantom II – (75357)

### Kit contents


- 1x Left arm
- 1x Right arm
- 1x Back stretcher
- 1x Front Stretcher
- 1x Minifigure mount
- 1x Minifigure mount lug
- 1x Adaptor position part
- 1x Wall plug (6x30mm)
- 1x Wall screw (4.5x50mm)
- 2x Small Command strip




## Wall Mount Instructions Ghost & Phantom II – (75357)




Remove the shown Lego assembly from the official display stand.



With the adaptor assembly seated in the Lego push the 4 Techinc pins from the Lego set to secure the adaptor in place.




## Wall Mount Instructions Ghost & Phantom II – (75357)




You can rotate the set to 8 positions and slide into the mount.

### Minifigure wall mount




Use the included 3M command strip to fix the minifigure mount lug to the wall.



Then slide the mount over the lug once the 3M command strip has had 8 hours to fully adhere to the wall.



## Wall Mount instructions Guardians of the Galaxy Ship – (76193)



Front facing configuration



Side facing configuration



From Lego ship stand

