


## Wall Mount Instructions For The Razor Crest – (75331)





## Wall Mount Instructions For The Razor Crest – (75331)

Before placing the set on the wall mount, Follow these steps.

Unclip both landing gear surrounds and release the legs by removing the technic axles as shown



Replace the surround and place the 3x4 tile as shown.





Remove the front landing gear foot and remove all top panels as shown.





## Wall Mount Instructions For The Razor Crest – (75331)





Using parts from the original display section, create the adaptor part for the minifgure display stand

