




Kit contents

- A 1x Left arm
- B 1x Right arm
- C 1x Wall stretcher
- D 1x Front Stretcher
- E 1x Ball joint cap
- F 2x ball joint halves
- G 1x ball joint connector
- H 1x Key piece
- I 1x Adaptor plate
- J 1x Info card mount
- K 2x Wall plug (6x30mm)
- L 2x Wall screw (4.5x50mm)
- M 1x Small Command strip











Fit the wall plugs into your wall using the spacing of the two mount points. Then Install the wall screws.


Do not over tighten (<u>do not</u> use a drill to tighten).




Feed the ball joint through the lower stretcher and screw the ball joint cap on to secure it in place.











House the key piece in the wall stretcher for future use. For the first few weeks you will need to periodically tighten the ball joint to maintain the tightness of the joint.



Apply the small 3M poster command strip to the Info card mount as shown. Then adhere the cleat to the wall holding in place for 30 seconds.

